



**Informal Interpretation Report
Number 7323**



Date April 14, 2014

Edition 2010

Section 1014 - 1018

Question:

when does a componet of exit access become a corridor per 1014 through 1018.

Answer

Based on the definition it is when it is enclosed.

Commentary:

CORRIDOR. An enclosed exit access component that defines and provides a path of egress travel to an exit.

EXIT ACCESS. That portion of a means of egress system that leads from any occupied portion of a building or structure to an exit.

Notice:

The Building Officials Association of Florida, in cooperation with the Florida Building Commission, the Florida Department of Business & Professional Regulation, ICC, and industry and professional experts offer this interpretation of the Florida Building Code in the interest of consistency in their application statewide. This interpretation is informal, non-binding and subject to acceptance and approval by the local building official.